

Precast Firepit Kit Assembly

To assemble your Precast Firepit, you will start with twelve (12) base pieces and four (4) cap pieces or top pieces.

Simply lay out your first four base pieces in a circle, apply adhesive/liquid nails to the top of each piece, then begin layering your next layer, alternating/rotating where your joints are placed for each layer (see photo).

After the pit has been assembled, you will apply the Insul Stick provided. You will need to coat the entire inside of the pit with this product. This will insulate the pit from the interior fire. (4) Burn only 1-2 logs at a time for first 30 days.

Any questions, please do not hesitate to call us @ 772-223-7287

